
MODULAR BIKE RACK 13208.UNI

INSTALLATION INSTRUCTIONS



Anchor ANCHOR.200 Chemical anchoring mass

- 1. For maximum installation durability provide a solid surface or footing.
- 2. Place the bike rack in the desired place and mark the anchoring spots on the ground.
- ₽Ę,

Ρ

- 3. Drill a D=12 mm and 200+ mm deep hole for ANCHOR.200.

- 4. Inject chemical anchoring mass HILTI HIT-ICE or similar according to the producer's instructions.
- 5. Insert threaded anchor ANCHOR.200 and wait till it hardens. Consult the producer for the hardening time.
- 6. Secure the bike rack to the ground with screws included in a set with the ANCHOR.200.

ANCHOR.200 is used if the existing paved surface doesn't provide sufficient support. In this case, a load-bearing footing, typically comprised of prefabricated concrete block/-s or poured-in concrete, has to be installed. The threaded part of ANCHOR.200 is anchored in the foot, thus providing secure and load-bearing support.

A set of ANCHOR.200 includes:

- Threaded rod with inner thread M8x30mm, L=200 mm 4 pcs.
- Ĩ.
- Stainless steel bolt M8x30mm A2 DIN7991 or DIN7380 4 pcs.

The Installation Manual has a suggestive character, with specific materials chosen by the construction executor. All measurements are approximate and are provided for informational purposes only. This Installation Manual remains subject to possible changes.



